



## **SE 0030-0003-0009 Drop detector sensor 1 or 2 – Connector/cable issue**

### **Call agent:**

- If, after rebooting, the issue persists, then your Support representative is needed to repair the printer on site.

### **Service engineer:**

1. Check that the Drop Detector PCA to Carriage Sensor PCA cable (NI\_52 or NI\_53) and connectors are properly connected, unbroken, and undamaged. **See Cable identification on page 1336.**
2. Replace cable or connector as needed.
3. Replace the Drop Detector PCA.
4. Replace the Carriage Sensor PCA.